


# CUSTOM RUBBER BELT FABRICATION

## BELT SPLICING OPTIONS



## FASTENER SPLICES





## VANNER EDGE

Vanner can be drilled and siped to improve flexibility on smaller diameter pulleys.


### Vanner Edge

#### Height

- 1/2"
- 3/4"
- 1"
- 1 1/2"
- 2"
- 2 1/2"
- 3"



## STANDARD V-GUIDES



## MINIMUM RECOMMENDED PULLEY DIAMETERS

Manufacturer's recommended pulley diameter for each belt specification should be used if larger than those listed below.

### Standard Cleats

Height	Pulley Dia.
1"	4"
1 1/2"	5"
2"	6"
2 1/2"	8"
3"	10"

### Heavy Duty Cleats

Height	Pulley Dia.
1"	5"
1 1/2"	8"
2"	10"
3"	12"
4"	14"
5"	18"
6"	18"

### Square Cleats

Height	Pulley Dia.
3/8" x 3/8"	3"
1/2" x 1/2"	4"
3/4" x 3/4"	8"
1" x 1"	10"

### Vanner Edges

Height	Solid	Drilled/Siped
1/2"	9"	6"
1"	10"	6"
1 1/2"	16"	8"
2"	18"	12"
2 1/2"	20"	12"
3"	24"	16"