



Description	Page #	Description	Page #
<b>I-Line Tees</b>	50	End	28
<b>I-Line True Y</b>	51	<b>Pipe Caps, continued</b>	
		Solid	28
<b>Q</b>		<b>S</b>	
<i>Q-Line Fittings-</i>	52	<i>Sample Valves-</i>	79-82
<b>Q-Line Clamps</b>	52	<b>304 Sample Valves</b>	80
Heavy Duty	52	Clamp	80
<b>Q-Line Caps</b>	52	NPT	80
End	52	<b>Angle Sample Valves</b>	81
Solid	52	Barb	81
<b>Q-Line Ferrules</b>	52	Clamp	81
Short	52	<b>In-Line Sample Valves</b>	82
		Barb	82
<b>J</b>		Clamp	82
<i>John Perry Fittings-</i>	39-43	<i>Sanitary Butt weld Fittings-</i>	53-63
<b>John Perry Caps</b>	43	<b>Butt weld Adapters</b>	54
End	43	Long	54
Solid	43	Hose	54
<b>John Perry Crosses</b>	43	Rubber	54
<b>John Perry Elbows</b>	42-43	Short	54
90°	42	<b>Butt weld Cross</b>	63
45°	42	<b>Butt weld Elbows</b>	54-57, 63
180°	43	45°	56
Return Bend	43	90°	54-55, 57
<b>John Perry Ferrules</b>	41-42	180°	63
Long	41	Bevel Seat	55-56
Plain	41	Clamp	55-56
Short	41, 42	Long	54, 56
Threaded	41, 42	Plain	55
<b>John Perry Lateral</b>	43	Return Bend	63
<b>John Perry Reducers</b>	43	Short	54, 56
<b>John Perry Tees</b>	43	Sweep	57
<b>John Perry True Y</b>	43	Tangents	54, 56
<b>John Perry Union Hex Nuts</b>	40	Threaded	55-56
<b>John Perry Wrenches</b>	40	<b>Butt weld Laterals</b>	63
Hex	40	<b>Butt weld Reducers</b>	60-62
Single Sided	40	Bevel Seat	62
Two Sided	40	Clamp	61
		Concentric	60-61
<b>P</b>		Eccentric	61-62
<i>Pipe Fittings-</i>	26-28	Plain	62
<b>Pipe Adapters</b>	28	<b>Butt weld Tees</b>	58-60
Butt weld	28	Bevel Seat	59
Clamp	28	Branch	58-59
Schedule 10	28	Clamp	58-59
Tube O.D.	28	Long	58
<b>Pipe Clamps</b>	27	Reducing	60
Single Pin	27	Run	58-59
Heavy Duty	27	Short	58
<b>Pipe Ferrules</b>	27-28	Threaded	59
long	27-28	<b>Butt weld True Y</b>	63
Schedule 5	27-28		
Schedule 10	27-28	<i>Sight Glass-</i>	166-167
Short	28		
<b>Pipe Caps</b>	28		