



Xtra Safe, Convenient Installation.

Flexco's DRX Impact Beds were engineered for safety and convenience from the very beginning. Our rugged system breaks down into individual components that can be easily hand carried to the installation site. One or two people can lift each component into place. Only simple tools are required and the entire process takes a matter of hours.



STEP 1

Use template to measure and cut holes.



STEP 2

Parts can be moved into place by one to two people.



STEP 3

Set Channel Crossbeams into position on the structure.



STEP 4

Measure out proper Channel Crossbeam distance and put into place.



STEP 5

Bolt down the Channel Crossbeams.