



STEP 6

Remove Support Arm mounting bolts and slide Support Arm to service position and rebolt.



STEP 7

Set bars in place over Support Arms.



STEP 8

Bolt bars to Support Arms.



STEP 9

Slide Support Arms from service position to run position.



STEP 10

Bolt Support Arms to Channel Crossbeams.



STEP 11

Clean up work area and remove tools.