



Xtra Safe, Convenient Installation.

Flexco's DRX Impact Beds were engineered for safety and convenience from the very beginning. Our rugged system breaks down into individual components that can be easily hand carried to the installation site. One or two people can lift each component into place. Only simple tools are required and the entire process takes a matter of hours.



STEP 1

Set rosta rail on structure, center, square up with cross braces and weld in place.



STEP 2

Compress rostas to gain 2.5" of additional space.



STEP 3

Remove Support Arms from Channel Crossbeams.



STEP 4

Set Channel Crossbeams into position and bolt.



STEP 5

Bolt Support Arms into service position.