
ASSEMBLE HOSE




Turn on crimper.

NOTE

Pump on crimper should not exceed 3000 PSI. Parker Hannifin will not accept responsibility for the operation of or provide warranty coverage for a crimiper that is operated by a power nti other than equipment supplied by Parker Hannifin for the express purpose of operating the crimper.

ASSEMBLE HOSE



While holding hose and fitting in position on die step, pull down on handle to activate crimper.

ASSEMBLE HOSE



Crimp fitting onto hose until die ring contacts base plate.

Keep fingers and hands away from die-pusher area.

personal injury.

WARNING

Failure to do so may result in

ASSEMBLE



Push handle to retract pusher.

ASSEMBLE



Remove hose assembly and die

ASSEMBLE HOSE



Repeat Steps 13-20 for the other end of hose if required. Turn off crimper.

Hose Assembly & Crimping