


Ball Valve Replacement Parts



BALL VALVE REPLACEMENT PARTS - 1/2" FP, 3/4" FP 1" FP, 1" SP, 1-1/2" FP & 2" SP

Size and Part Number

DESCRIPTION	1/2" FP	3/4" FP	1" FP	1" SP	1-1/4" FP	1-1/2" FP	2" SP
Shaft	4S300-00	4S300-00	4H446-00	4S300-00	4S301-00	4S301-00	4S301-00
Handle	4L100-00	4L100-00	4H722-00	4L100-00	4L101-00	4L101-00	4L101-00
Body	4B200-00	4B200-00	4H384-00	4B200-00	4B201-00	4B201-00	4B201-00
Ball	4B100-00	4B100-00	4H389-00	4B100-00	4B101-00	4B101-00	4B101-00
End Cap	4E100-00	4E101-00	4H372-00	4E102-00	4E122-00	4E103-00	4E104-00
Seat	4S100-20	4S100-20	4H374-00	4S100-20	4S101-20	4S101-20	4S101-20
Upper Bearing	4B300-20	4B300-20	—	4B300-20	—	—	—
Upper Bearing 1-1/2"	—	—	—	—	4H013.20	4H013.20	4H013.20
Lower Bearing	4B300-20	4B300-20	—	4B300-20	4B301-20	4B301-20	4B301-20
O-Ring	4S200-00	4S200-00	—	4S200-00	4H038-00	4H038-00	4H038-00
O-Ring Shaft	—	—	4H356-00	—	—	—	—
O-Ring Body	—	—	4H379-00	—	—	—	—
Body Bolt	—	—	4H422-00	—	4H001-00	4H001-00	4H001-00
Body Bolt 1/4"x2-3/4"	4H000-00	4H000-00	—	4H000-00	—	—	—
Lockwasher	—	—	4H437-00	—	—	—	—
Lockwasher 1/4"	4H014-00	4H014-00	—	4H014-00	—	—	—
Lockwasher 3/8"	—	—	—	—	4H017-00	4H017-00	4H017-00
Nut	—	—	4H396-00	—	—	—	—
Nut 1/4" HEX	4H026-00	4H026-00	—	4H026-00	—	—	—
Nut 3/8"x21/64" HEX	—	—	—	—	4H024-00	4H024-00	4H024-00
Handle Screw	—	—	4H347-00	—	—	—	—
Handle Bolt 8/32"x1/2"	4H030-10	4H030-10	—	4H030-10	—	—	—
Handle Bolt 1/4"x5/8"	—	—	—	—	4H008-00	4H008-00	4H008-00
Handle Washer 1/4"x1"	—	—	—	—	4H016-10F	4H016-10F	4H016-10F