

# Alligator® Staple Gold Class™ from Flexco

Profiled front edge of the drive punch creates proper compression set of the front edge of the fastener plate.



Initial Drive Base: Fasteners and belt are inserted into this Initial Drive Base where the pre-staked staples are driven through the belt with simple trigger pulls.



Final Set Base: After the fasteners are initially set, move belt splice to the Final Set Base where the staples receive their final set and the compression fit is obtained.



Ordering Information		
Description	Item Code	Ordering Number
<b>Alligator® Staple Gold Class™</b>		
Power Driver	55541	RS-GOLD-DRIVER
<b>Initial Drive Base</b>		
6" Initial Drive Base	55542	RS-GOLD-INITIAL-6
12" Initial Drive Base	55543	RS-GOLD-INITIAL-12
24" Initial Drive Base	55544	RS-GOLD-INITIAL-24
36" Initial Drive Base	55548	RS-GOLD-INITIAL-36
48" Initial Drive Base	55551	RS-GOLD-INITIAL-48
<b>Final Drive Base</b>		
6" Final Set Drive Base	55545	RS-GOLD-FINAL-6
12" Final Set Drive Base	55546	RS-GOLD-FINAL-12
24" Final Set Drive Base	55547	RS-GOLD-FINAL-24
36" Final Set Drive Base	55549	RS-GOLD-FINAL-36
48" Final Set Drive Base	55552	RS-GOLD-FINAL-48
<b>Replacement Parts</b>		
Guide Block	55554	ST7-5
Punch	55555	ST7-9
Wear Plate (Final Set Base)	55556	ST7-29
Safety Guard	55561	ST7-34
Regulator Hose Assembly	55562	ST7-35



2525 Wisconsin Avenue  
Downers Grove, IL 60515-4200 U.S.A.  
Telephone: (630)-971-0150  
Fax: (630)-971-1180  
E-mail: info@flexco.com



www.flexco.com

**GOODYEAR**  
RUBBER PRODUCTS INC.

Call Toll Free: **1-866-711-4673**  
WebSales@GoodyearRubberProducts.com

**We Ship  
World Wide**