

FASTENER-V-BELT REPLACEMENT CHART

FOR "A" SECTION ENDLESS V-BELT

Endless V-Belt No.	Cut Your Fastener-V-Belting
A-26	26 ¹ / ₂ "
A-31	31 ¹ / ₁₆ "
A-33	33 ⁷ / ₁₆ "
A-35	35 ⁷ / ₁₆ "
A-38	38 ³ / ₈ "
A-42	42 ³ / ₈ "
A-43	43 ³ / ₈ "
A-46	46 ⁵ / ₁₆ "
A-48	48 ⁵ / ₁₆ "
A-51	51 ⁵ / ₁₆ "
A-53	53 ¹ / ₄ "
A-55	55 ¹ / ₄ "
A-56	56 ¹ / ₄ "
A-60	60 ³ / ₁₆ "
A-62	62 ³ / ₁₆ "
A-64	64 ³ / ₁₆ "
A-66	66 ³ / ₁₆ "
A-68	68 ³ / ₁₆ "
A-70	70 ¹ / ₈ "
A-71	71 ¹ / ₈ "
A-75	75 ¹ / ₈ "
A-78	78 ¹ / ₈ "
A-80	80 ¹ / ₈ "
A-85	85"
A-90	90"
A-96	95 ¹⁵ / ₁₆ "
A-105	104 ⁷ / ₈ "
A-112	111 ³ / ₁₆ "
A-120	119 ³ / ₄ "
A-128	127 ¹ / ₁₆ "
A-136	135 ⁹ / ₁₆ "
A-144	143 ⁹ / ₁₆ "

No. A312 Alligator V-Belt Fastener is recommended for joining "A" Section Fastener-V-Belting.

FOR "B" SECTION ENDLESS V-BELT

Endless V-Belt No.	Cut Your Fastener-V-Belting
B-35	35 ³ / ₁₆ "
B-38	38 ¹ / ₈ "
B-42	42 ¹ / ₁₆ "
B-46	46"
B-48	48"
B-51	50 ¹⁵ / ₁₆ "
B-53	52 ¹ / ₁₆ "
B-55	54 ⁷ / ₈ "
B-56	55 ⁷ / ₈ "
B-60	59 ³ / ₁₆ "
B-62	61 ³ / ₄ "
B-64	63 ³ / ₄ "
B-65	64 ³ / ₄ "
B-66	65 ¹ / ₁₆ "
B-68	67 ¹ / ₁₆ "
B-71	70 ⁵ / ₈ "
B-75	74 ⁹ / ₁₆ "
B-78	77 ¹ / ₂ "
B-81	80 ¹ / ₂ "
B-83	82 ⁷ / ₁₆ "
B-85	84 ⁷ / ₁₆ "
B-90	89 ⁵ / ₁₆ "
B-93	92 ⁵ / ₁₆ "
B-97	96 ³ / ₁₆ "
B-100	99 ³ / ₁₆ "
B-103	102 ¹ / ₈ "
B-105	104 ¹ / ₁₆ "
B-108	107 ¹ / ₁₆ "
B-112	111"
B-120	118 ⁷ / ₈ "
B-124	122 ³ / ₁₆ "
B-128	126 ³ / ₄ "
B-133	131 ¹ / ₁₆ "
B-136	134 ⁹ / ₁₆ "
B-144	142 ¹ / ₂ "
B-158	156 ¹ / ₄ "
B-162	160 ³ / ₁₆ "
B-173	171"
B-180	177 ¹⁵ / ₁₆ "
B-195	192 ¹ / ₁₆ "
B-210	207 ⁷ / ₁₆ "
B-225	220 ³ / ₄ "
B-240	235 ¹ / ₂ "
B-255	250 ¹ / ₄ "
B-270	265"
B-285	279 ¹³ / ₁₆ "
B-300	294 ⁹ / ₁₆ "

No. B437 Alligator V-Belt Fastener is recommended for joining "B" section Fastener-V-Belting.

FOR "C" SECTION ENDLESS V-BELT

Endless V-Belt No.	Cut Your Fastener-V-Belting
C-51	51 ³ / ₁₆ "
C-60	60 ¹ / ₁₆ "
C-68	67 ¹⁵ / ₁₆ "
C-75	74 ¹³ / ₁₆ "
C-81	80 ³ / ₄ "
C-85	84 ¹ / ₁₆ "
C-90	89 ⁹ / ₁₆ "
C-96	95 ¹ / ₂ "
C-105	104 ⁵ / ₈ "
C-112	111 ¹ / ₄ "
C-120	119 ¹ / ₈ "
C-128	127"
C-136	134 ³ / ₈ "
C-144	142 ³ / ₄ "
C-158	156 ¹ / ₂ "
C-162	160 ⁷ / ₁₆ "
C-173	171 ⁵ / ₁₆ "
C-180	178 ³ / ₁₆ "
C-195	192 ¹⁵ / ₁₆ "
C-210	207 ¹ / ₁₆ "
C-225	220 ¹ / ₂ "
C-240	235 ¹ / ₄ "
C-255	250"
C-270	264 ¹³ / ₁₆ "
C-285	279 ⁹ / ₁₆ "
C-300	294 ⁵ / ₁₆ "
C-315	309 ¹ / ₁₆ "
C-330	323 ⁷ / ₈ "
C-345	338 ⁵ / ₈ "
C-360	353 ³ / ₈ "
C-390	382 ¹⁵ / ₁₆ "
C-420	412 ⁷ / ₁₆ "

No. C531 Alligator V-Belt Fastener is recommended for joining ¹/₂" thick "C" section Fastener-V-Belting.

FOR "D" SECTION ENDLESS V-BELT

Endless V-Belt No.	Cut Your Fastener-V-Belting
D-120	120 ¹ / ₄ "
D-128	128 ¹ / ₄ "
D-144	144"
D-158	157 ⁷ / ₈ "
D-162	161 ³ / ₈ "
D-173	172 ⁵ / ₈ "
D-180	179 ⁵ / ₈ "
D-195	194 ¹ / ₂ "
D-210	209 ¹ / ₄ "
D-225	221 ⁵ / ₈ "
D-240	236 ¹ / ₂ "
D-255	251 ³ / ₈ "
D-270	266 ¹ / ₈ "
D-285	281"
D-300	295 ⁷ / ₈ "
D-315	310 ³ / ₄ "
D-330	325 ¹ / ₂ "
D-345	340 ³ / ₈ "
D-360	355 ¹ / ₄ "
D-390	385"
D-420	414 ⁵ / ₈ "
D-480	474"
D-540	533 ³ / ₈ "
D-600	592 ³ / ₄ "

No. D750 Alligator V-Belt Fastener is recommended for joining "D" section Fastener-V-Belting.

MANUFACTURERS' NUMBERING SYSTEMS

There are several numbering systems used by V-Belting manufacturers. All the numbers in each column identify the same length belts.

A-26	B35	C51	D120
26A	35B	51C	120D
2A6	3B5	5C1	1D20

FLEXIBLE STEEL LACING COMPANY

2525 WISCONSIN AVENUE, DOWNERS GROVE, ILLINOIS 60515 U.S.A.

GOODYEAR
RUBBER PRODUCTS INC.

Call Toll Free: **1-866-711-4673**
WebSales@GoodyearRubberProducts.com

**We Ship
World Wide**