

# OETIKER Installation Tools

## Manual or pneumatic OETIKER Pincers for the safe and correct installation of Clamps

OETIKER Clamps and Rings should be installed with the tools developed for them. They ensure correct installation and optimum product performance. When electronically-controlled tools are used, the closure process can be continuously monitored.

### Manual Pincers



Pincer for Ear Clamps  
Standard Jaw




Pincer for Ear Clamps  
Side Jaw



Pincer for Ear Clamps  
Narrow Jaw



Pincer for  
Stepless Ear Clamps  
– Heavy-Duty range



Pincer for  
Stepless® Low Profile Clamps 192



Pincer with return spring for  
Stepless® Low Profile Clamps



Pincer with return spring for  
ER Clamps



Flexible screwdriver

For further information, please see the OETIKER Tool Catalogue.