



<b>Introduction .....</b>	<b>A-2</b>	<b>30 Series .....</b>	<b>A-27 to A-30</b>
<b>Coupling Selection &amp; Ordering Guide.....</b>	<b>A-4</b>	Couplers .....	A-29 to A-30
<b>Interchange Match-up Chart.....</b>	<b>A-5</b>	<b>Twist-Lock Couplings .....</b>	<b>A-31</b>
<b>Industrial Interchange Nipples .....</b>	<b>A-6 to A-7</b>	Couplers .....	A-32
<b>General Purpose Couplings</b>		Nipples.....	A-32
<b>Manual Connect.....</b>	<b>A-8</b>	<b>Special Purpose Couplings</b>	
10 Series.....	A-9	<b>Standard - NonMar .....</b>	<b>A-33</b>
Couplers .....	A-10	Tool-Mate Series Couplers - Composite .....	A-34
Nipples.....	A-11	<b>Exhaust - NonMar .....</b>	<b>A-35</b>
20 Series.....	A-12	Tool-Mate Series Couplers - Composite .....	A-36
Couplers .....	A-13	<b>Exhaust - Steel.....</b>	<b>A-37</b>
50 Series.....	A-14	E-z-mate Series .....	A-37
Couplers .....	A-14	Couplers .....	A-38
Nipples.....	A-15	<b>Breathing Air</b>	
70 Series.....	A-16	CJ Series .....	A-39
Couplers .....	A-16	Couplers .....	A-40
Nipples.....	A-16	Nipples.....	A-40
<b>Push-to-Connect.....</b>	<b>A-17</b>	<b>Accessories</b>	
RF Series .....	A-18	SC Series .....	A-41
Couplers .....	A-19	Hose Fittings.....	A-42
Nipples.....	A-20	Blowguns	
Tool-Mate Series .....	See pages A-33 to A-36	Controlled Pressure .....	A-43
HF Series .....	A-21	Full Pressure .....	A-43
Couplers – 1/8" .....	A-22	BG Series .....	A-44
Nipples – 1/8" .....	A-22	Two-Way Valves .....	A-45
Couplers – 1/4", 3/8" & 1/2".....	A-23	Air Line Filters .....	A-45
HF Series Heavy Duty Couplers – 1/4" & 3/8" .....	A-24		
HA Series.....	A-25		
Couplers .....	A-25		
Nipples.....	A-15		
Universal Coupler .....	A-26		
Couplers .....	A-26		