

## Dust Plugs and Dust Caps

### Hydraulic Quick Couplings

#### HP Series

Body Size (in.)	Dust Plug Part Number Rubber	Dust Cap Part No. Rubber
1	HPP-100	HPC-100
1 1/2	HPP-150	HPC-150

#### 4000 Series & 5000 Series



Body Size (in.)	Dust Plug Part No. Steel	Dust Plug Part No. Rubber	Dust Cap Part No. Steel	Dust Cap Part No. Rubber
1/4	-	5205-2M*	-	5209-2M*
3/8	-	5205-3	-	5209-3
1/2	5005-4	5205-4M*	5009-4	5209-4M*
3/4	-	5205-5	-	5209-5
1	-	5205-6	-	5209-6

\* Designates all rubber material. (Not shown at left)

#### NS Series



Body Size (in.)	Part Number Rubber
3/8	NR-37
1/2	NR-50
3/4	NR-75
1	NR-100

Protective cover fits either half.


#### FF Series, FC Series, FH Series & FS Series



Body Size (in.)	Dust Plug Part Number Rubber	Dust Cap Part No. Rubber
1/4*	FR-25	FR-25
3/8	NR-50	NR-37
1/2	FR-501	FR-502
3/4	FR-751	FR-752
1	FR-1001	FR-1002

\* FR-25 fits both halves

#### FE Series, FEC Series, FEM Series



Body Size (in.)	Dust Plug Part Number Rubber	Dust Cap Part No. Rubber
1/4	FR-25	FR-25
3/8	NR-50	NR-37
1/2	FR-501	FER-502
3/4	FR-751	FER-752
1	FR-1001	FER-1002

#### 6100 Series



Body Size (in.)	Dust Plug Part No. Brass	Dust Cap Part No. Brass
3/4	6109-08	6108-08
1	6109-16	6108-16
1 1/4	6109-20	6108-20
1 1/2	6109-24	6108-24

Quick Coupling Division