



## Table of Contents

### Diagnostic Products



<b>Introduction .....</b>	<b>F-2</b>	<b>PDF Series Flow Sensors .....</b>	<b>F-17</b>
<b>Table of Contents.....</b>	<b>F-3</b>	<b>Test Port Couplings</b>	
<b>Product Selection Guide.....</b>	<b>F-4</b>	PD Series.....	F-18 - F-20
<b>ServiceJunior™ .....</b>	<b>F-5</b>	Couplers & Dust Cap.....	F-19
<b>SensoControl® Serviceman™</b>		Nipples.....	F-19 - F-20
General.....	F-6	Tube End Nipples .....	F-20
Schematic.....	F-7	PDFS Series - Fluid Sampling.....	F-21
Technical Data .....	F-8	Couplers .....	F-21
Tachometer, Cable & Temp Sensor .....	F-8 - F-9	Nipples.....	F-21
Test Meter Kits .....	F-10	PDP Series .....	F-22 - F-23
<b>SensoControl® ServiceMaster™</b>		Couplers & Dust Cap.....	F-22
General.....	F-11	Nipples.....	F-23
Schematic.....	F-12	Transducer Adapters.....	F-24
Technical Data .....	F-13	Flexible Hose .....	F-24
SensoControl® Transducer.....	F-14	EMA3 Series.....	F-25
Components and Accessories.....	F-15	Nipples.....	F-25
Test Meter Kits .....	F-16	Gauge Adapter & Union .....	F-26
		Ordering Information.....	F-27