






















90° Elbows	ELO Union Elbow  A23	EMLO Union Elbow - mm Hex  A23	WELO Bulkhead Union  A24	WEMLO Bulkhead Union - mm Hex  A24	C6LO ORFS Swivel Elbow  A25
	C6MLO Swivel Elbow - mm Hex  A25	AOEL6 ORFS Swivel / SAE-ORB  A25	C5OLO ORFS / SAE-ORB  A25	CC5OLO ORFS / SAE-ORB - Long  A26	CLO ORFS / NPTF  A26
C87OMLO ORFS / ISO 6149 - Long  A27	C8OMLO ORFS / Metric-ORR  A27	C4OMLO ORFS / BSPP-ORR  A28	Tees	JLO Union Tee  A28	JMLO Union Tee - mm Hex  A28
WJLO Bulkhead Branch  A28	WJMLO Blkhd Branch - mm Hex  A29	WJJLO Bulkhead Run  A29		S6LO ORFS Swivel Branch  A30	S6MLO Swivel Branch - mm Hex  A30
R6LO ORFS Swivel Run  A31	R6MLO Swivel Run - mm Hex  A31	S5OLO SAE-ORB Branch Tee  A31	R5OLO SAE-ORB Run Tee  A32	SLO NPTF Branch Tee  A32	S87OMLO ISO 6149 Branch Tee  A32
R87OMLO ISO 6149 Run Tee  A33	S4OMLO BSPP-ORR Branch Tee  A33	R4OMLO BSPP-ORR Run Tee  A34	Crosses	KLO Union Cross  A34	KMLO Union Cross - mm Hex  A34
Plugs, Caps and Bleed Adapters	PNLO ORFS Plug  A35	PNMLO ORFS Plug - mm Hex  A35	FNL ORFS Cap  A35	FNML ORFS Cap - mm Hex  A35	