

Table of Contents

Port End Assembly	T3	Pre-set of the Retaining Ring	T32
Parallel Thread Ports	T3	Pre-set Using the Fitting Body or Hardened Pre-assembly Tool	T32
Adjustable Port End Assembly	T4	Pre-set Inspection	T32
Non-adjustable Port End Assembly	T4	Pre-set Using EO-Karrymat, EOMAT III, Hydra-Tool or Hyferset	T32
Tapered Thread Ports	T6	Installation	T33
Tapered Thread Port Assembly	T7	Re-assembly with Replacement of Sealing Ring (DOZ)	T33
Flange Ports	T8	EO-2 Troubleshooting Guide	T33
Troubleshooting Port End Connections	T9	24° Flareless Bite	T34
Tube End Assembly	T12	Bulkhead Locknut Assembly	T35
Tube End Preparation	T12	Pipe Swivel Assembly	T35
Seal-Lok and Seal-Lok Lite Assembly	T13	Routing and Clamping	T36
Sleeve Attachment	T13	Routing of Lines	T36
Flanging	T13	Tube Clamping	T37
Brazing	T16	Layout Data for Tube, Pipe and Hose Clamps	
Final Installation	T17	Standard (Inch) and Series A (Metric)	T37
Seal-Lok Troubleshooting Guide	T19	Heavy Series (Inch) and Series C (Metric)	T38
Triple-Lok and Triple-Lok 2 Assembly	T20	Twin Series (Inch) and Series B (Metric)	T38
Flaring	T20	Tools for Tube Bending	T39
Installation	T21	Mandrel Bending Tools	T39
Triple-Lok Troubleshooting Guide	T22	Plumbing and Assembly Hints	T40
Ferulok Assembly	T23	Assembly Heights and Clearance	T41
Ferrule Pre-set	T23		
Ferulok Troubleshooting Guide	T25		
24° Flareless Bite	T26		
Intru-Lok Assembly	T27		
Cutting, Deburring and Cleaning	T27		
Installation	T27		
Remake	T27		
Intru-Lok Troubleshooting Guide	T27		
EO Assembly	T28		
Pre-set of Progressive Ring	T28		
Pre-set Using the Fitting Body or Hardened Pre-assembly Tool	T28		
Pre-set Inspection	T29		
Pre-set Using EO-Karrymat, EOMAT III, Hydra-Tool or Hyferset	T29		
Installation	T29		
Steps for Proper Assembly of Support Sleeve (VH)	T30		
EO Troubleshooting Guide	T31		
EO-2 Assembly	T32		